

Aperture**Bag 1**

Resistor 100R	1
Resistor 220R	1
Resistor 470R	1
Resistor 1k	2
Resistor 2,2k	1
Resistor 4,7k	3
Resistor 8,2k	1
Resistor 10k	1
Resistor 15k	1
Resistor 47k	2
Resistor 100k	1
Resistor 220k	2
Resistor 470k	1
Resistor 1M	2
Resistor 2,2M	1
Trimmer 1/4" 10k	1
1N456	2
1N5817	1

Bag 2

MKT 10nF	1
MKT 1uF	4
MLCC 0,1uF	1
Elko 4,7uF	3
Elko 22uF	1
Elko 100uF	2

Bag 3

MPSA14	3
2N3904	2
3 Pin Socket	5
LED 5mm rot	1
LED Clip 5mm	1

Bag 4

Potentiometer 16mm 10k lin vert. pcb	1
Potentiometer 16mm 50k lin vert. pcb	2
Bumper 12,7mm (back of pots)	3
6,3mm phone jack Mono	1
6,3mm phone jack Stereo	1
Toggleswitch DPDT	1
Battery clip	1
Self adhesive feet	1
DC jack isolated	1
Footswitch 3PDT	1

Wire bag	1
Aperture pcb	1