

Echo Nightmare

Bag 1

Resistor 100R	1
Resistor 220R	1
Resistor 390R	1
Resistor 680R	1
Resistor 1k	2
Resistor 2,7k	1
Resistor 3,3k	1
Resistor 3,6k	1
Resistor 4,7k	1
Resistor 6,8k	2
Resistor 8,2k	1
Resistor 10k	12
Resistor 13k	2
Resistor 15k	1
Resistor 82k	1
Resistor 470k	2
Resistor 1M	1
1N5817	3

Bag 2

Keramik 220pF	1
Keramik 470pF	1
MKT 2,2nF	2
MKT 10nF	3
MKT 33nF	1
MKT 47nF	1
MKT 82nF	1
MKT 0,1uF	4
MKT 0,68uF	1
Elko 1uF	8
Elko 10uF	3
Elko 100uF	4
Elko 220uF	1

Bag 3

8 Pin IC socket	2
16 Pin IC socket	2
NE5532P (=MC33172P)	1
TC1044	1
XR2206	1
PT2399	1
LED 5mm red	1
LED Clip 5mm	1

Bag 4

Poti 16mm 100k log vertical pcb	2
Poti 16mm 1M log vertical pcb	2
Poti 16mm 100k rev log vertical pcb	2
Poti 16mm 100k lin vertical pcb	1
Toggleswitch SPDT	1
Toggleswitch DPDT	1
Bumper 12,7mm (back of pots)	6
6,3mm phone jack mono	2
Bumper	1
DC jack isolated	1
Footswitch 3PDT	1

Wire bag	1
----------	---

PCB Echo Nightmare	1
3PDT Board	1