

Sinner Bass Drive
 PCB Guitar Mania

Beutel 1

Widerstand 100R	2
Widerstand 1k	4
Widerstand 2,2k	1
Widerstand 3,2k	2
Widerstand 3,3k	3
Widerstand 4,7k	1
Widerstand 6,2k	1
Widerstand 10k	14
Widerstand 22k	8
Widerstand 33k	2
Widerstand 100k	6
Widerstand 330k	2
Widerstand 1M	3
Zener 12V 1W	1
1N4001	1
1N5817	1

Beutel 2

Keramik 33pF	4
Keramik 220pF	2
Keramik 470pF	1
MKT 1,2nF	1
MKT 2,2nF	1
MKT 10nF	4
MKT 22nF	8
MKT 47nF	3
MKT 0,1uF	1
Elko 2,2uF	3
Elko 10uF	3
Elko 47uF	1
Elko 220uF	2

Beutel 3

8 Pin IC Socket	2
14 Pin IC Socket	2
TL072	2
TL074	2
LED 5mm rot	1
LED Clip 5mm	1

Beutel 4

Kippschalter SPDT	1
Kippschalter DPDT	1
Poti 16mm 100k lin gewinkelt print	6
KlebefüÙe 12,7mm (Rückseite Poti)	6
6,3mm KliBu offen Mono	2
Hicon HI-X3DM XLR Buchse male	1
KlebefüÙe	1
DC Buchse isoliert	1
Fußschalter 3PDT	1

Drahtpack	1
Platine Sinner Bass Drive	1
3PDT Platine	1