

Train Crash

PCB Guitar Mania

Bag 1

Resistor 10R	1
Resistor 220R	1
Resistor 470R	1
Resistor 1k	3
Resistor 2,2k	4
Resistor 3,3k	1
Resistor 4,7k	7
Resistor 10k	5
Resistor 13k	2
Resistor 18k	1
Resistor 68k	1
Resistor 47k	2
Resistor 100k	2
Resistor 1M	3
Resistor 4,7M	1
Zener 1,8V 0,5W	2
1N4148	4
1N5817	1

Bag 2

Keramik 220pF	4
MKT 3,3nF	1
MKT 10nF	2
MKT 12nF	1
MKT 22nF	2
MKT 47nF	3
MKT 0,1uF	1
MKT 0,22uF	1
MKZ 2,2uF	3
Elko 22uF	3
Elko 220uF	1
Elko 470uF	1

Bag 3

8 Pin IC Socket	2
OPA2134	2
LED 5mm red	1
LED Clip 5mm	1

Bag 4

Poti 16mm 10k lin vert. pcb	2
Poti 16mm 50k lin vert. pcb	1
Bumper 12,7mm (back of pots)	3
Toggleswitch 1x on-off-on	3
Toggleswitch SPDT	1
6,3mm phone jack mono	2
Bumper	1
DC jack isolated	1
Footswitch 3PDT	1

Wire bag	1
PCB Train Crash	1
3PDT Board	1